

New

For Mold Clamping System Remote Monitoring System

Remote Monitoring of Mold Clamping System









For Mold Clamping System

Remote Monitoring System

Wireless Model

Model YMB-W




Remotely Monitor Status of Mold Clamping System


Easy Setup, Provides Machine Condition and User Information Wirelessly Accurate data transmission enables quick machine recovery.

Features


An error status during mold clamping can be fetched to a smart phone or tablet and the data will be sent to Kosmek via a user's communication network. This allows prompt and accurate condition information.

Quick recovery from a system error improves service accuracy!





After Introducing
Remote Monitoring System





Image



Mold Clamping System

Operation Panel



Control Unit





Paring with Mold Clamping System to Confirm Conditions



Send the Information of Mold Clamping System to Kosmek



Check details.

And we will respond immediately.

Model No. Indication





1 Design No.

Revision Number

Mold Change Method

V: Vertical Mold Change System (Horizontal Molding Machine)

H: Horizontal Mold Change System (Horizontal Molding Machine)

R: Vertical Molding Machine *1

Notes:

- %1. Please contact us for the control method of vertical molding machine.
 - 1. Contact us for specifications and external dimensions of the options.

3 Applicable Clamp Model No.

Refer to the following catalog for further information of each series.

G series (Hydraulic Clamp) : Refer to CAT. NO. GBB001-□□-GB **H series (Pneumatic Clamp)** : Refer to CAT. NO. HZ-□□-GB **Q series (Pneumatic Clamp)** : Refer to CAT. NO. QM-□□-GB

4 Pressure Source * When using Air Valve Unit

10: With Pressure Switch in the Clamp Circuit **00**: Without Pressure Switch in the Clamp Circuit

5 Option

Blank: Standard (Operation Panel in Japanese)

: With Mold Confirmation Proximity Switch

: With Mold Confirmation Proximity Switch (6-8 pcs. on each side)

: Operation Panel in English Ν : Operation Panel in Chinese C

: With Remote Monitoring Function (Wireless Model) *2



Note:

*2. A terminal device such as tablet or smart phone is not included. It should be prepared by customer.

Reference Catalog List

Catalog Name	Catalog Number
G series (Hydraulic Clamp)	GBB001-□□-GB
H series (Pneumatic Clamp)	HZ-□□-GB
Q series (Pneumatic Clamp)	QM-□□-GB


Refer to each series' catalog for specifications, dimensions and details not related to 50 Option W: With Remote Monitoring Function (Wireless Model).




Specifications: Bluetooth


Communication Method (Profile)	Bluetooth Standard ver. 4.1 (Bluetooth Low Energy)
Output	Bluetooth Standard Power Class 2 (TX power +4dBm)
Communication Distance Range	Line-of-Sight Range within about 2.5m ~ 10m
Frequency Band	2.4GHz Band (2.402GHz - 2.480GHz)
Modulation System	GFSK
Applicable Bluetooth Protocol	GAP / GATT / SM / LL / RF-PHY
Mobile Operating System	iOS 10.3.3 or later version / Android 6.0 or later version
Certification	CE Marking [EU]
	FCC 【North America】
	Technical Regulations Conformity Certification / Construction Type Certification (Prev. TELEC) [Japan]

External Dimensions: Operation Panel





External Dimensions : Control Unit



Notes:

- 1. The bracket can be mounted in any direction.
- 2. The bracket is shipped mounted as shown in the drawings above.

Operation Outline: Initial Setup ~ Login

Refer to the instruction manual for further information.

User-Friendly Application Enables Quick and Simple Initial Setup • User Registration

Activate the Application

Download the Remote Monitoring System Application


Find the Bluetooth

Tap [scan] to find the Bluetooth.

Pair with the Bluetooth

Tap [KOSMEK-YMB2] on the paring list to pair with your device.








User Data Registration


Enter user's information to register.



Operation Method of YMB Operation Panel

Operate YMB Operation Panel to Log In

• Turn the key switch "MOLD CHANGE" ON while pressing "RESET".





Operation Outline: Display ~ Send Status Refer to the instruction manual for further information.

Quick Recovery of Mold Clamping System Possible by sending accurate data to us while checking its status.


Detailed Menu

Select an item on the detailed menu you would like to check.



Clamping Status

Displays the same item as Operation Panel.



Input and Output Signal

Displaying I/O status enables to find errors immediately.




Operation History

Displays the operation history of clamping system.



Email Recipients

Able to enter and record email recipients.



Sending Messages

Able to enter comments and send them to us.





Magnet Clamp System

The world's thinnest (37mm) magnet plate ensures safety and securely clamps the mold.



Pneumatic Clamp System

injection molding machines.

Eco-friendly air operated clamps exert powerful clamping force and are equipped with a mechanical locking system. New 40ton / 50ton models have been introduced for extra-large



Hydraulic Clamp System

Hydraulic clamps have powerful clamping force in a compact body. Kosmek also offers units that generate hydraulic pressure using only factory air.

Harmony in Innovation

HEAD OFFICE 1-5, 2-Chome, Murotani, Nishi-ku, Kobe 651-2241 TEL.+81-78-991-5162 FAX.+81-78-991-8787

KOSMEK (U.S.A.) LTD. BRANCH OFFICE (U.S.A.)

650 Springer Drive, Lombard, IL 60148 USA

TEL. +1-630-620-7650 FAX. +1-630-620-9015

KOSMEK USA Mexico Office MEXICO REPRESENTATIVE OFFICE

Blvd Jurica la Campana 1040, B Colonia Punta Juriquilla Queretaro, QRO 76230 Mexico

TEL.+52-442-161-2347

BRANCH OFFICE (EUROPE) KOSMEK FUROPE GmbH

Schleppeplatz 2 9020 Klagenfurt am Wörthersee Austria TEL.+43-463-287587 FAX.+43-463-287587-20 FAX.+43-463-287587-20

BRANCH OFFICE (INDIA) KOSMEK LTD - INDIA

F 203, Level-2, First Floor, Prestige Center Point,

Cunningham Road, Bangalore -560052 India TEL.+91-9880561695

THAILAND REPRESENTATIVE OFFICE 67 Soi 58, RAMA 9 Rd., Suanluang, Suanluang, Bangkok 10250

TEL. +66-2-300-5132 FAX. +66-2-300-5133

- FOR FURTHER INFORMATION ON UNLISTED SPECIFICATIONS AND SIZES, PLEASE CALL US.
- SPECIFICATIONS IN THIS LEAFLET ARE SUBJECT TO CHANGE WITHOUT NOTICE





http://www.kosmek.com



WAHLTEC GmbH Ravensburger Str. 14 88361 Altshausen T: +49 (7584) 9238883 F: +49 (7584) 9238887

www.wahltec.de